



FLEXAMAT INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flexamat[®]
 Address: 3153 Madison Road
 Cincinnati, OH 45209
 Telephone: 513-772-6689
 Fax: 513-772-6690
 Contact: Matt Motz
 Matt@Flexamat.com
 Website: www.Flexamat.com

Distributed by:



www.quicksupplydm.com
 (515)289-1271

CONSTRUCTION NOTES:

1. GRADE A UNIFORM SUBGRADE. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS. FLEXAMAT BLOCKS HAVE A 2.25" PROFILE; GRADE SO THAT THE TOP OF THE MAT WILL HAVE A FLUSH TRANSITION TO THE SLOPE.
2. INSTALL FLEXAMAT ROLLS. ROLL WIDTHS ARE 8', 10', 12', & 16'. MATS SHALL BE INSTALLED SO THAT THE FLEXAMAT EXTENDS 3'-0" ABOVE THE ANTICIPATED HIGH WATER ELEVATION AND 3'-0" BELOW ANTICIPATED LOW WATER ELEVATION.
3. SPREAD SHREDDED TOPSOIL OVER MAT. SWEEP SOIL BETWEEN BLOCKS AND USE SOIL TO TRANSITION FROM MAT TO SLOPE.
4. SEED THE AREA WITH SITE SPECIFIC SEED MIX. NATIVE GRASSES AS WELL AS OTHER LITTORALS WILL GROW WITHIN MAT.
5. ABUT THE NEXT SECTION OF MAT TIGHTLY TO THE PREVIOUS SECTION. A CONCRETE SAW MAY BE NECESSARY TO CUT MAT TO FIT TIGHTLY TO ADJACENT SECTION OF MAT.

FLEXAMAT[®]
SHORELINE ARMORING DETAIL
NTS