



FLEXAMAT® INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flexamat
 Address: 3153 Madison Road
 Cincinnati, Ohio 45209
 Telephone: 513-772-6689
 Fax: 513-772-6690
 Contact: Matt Motz
 Matt@Flexamat.com
 Website: www.Flexamat.com

CONSTRUCTION NOTES:

1. GRADE A UNIFORM SUBGRADE. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF STICKS, ROOTS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS.
2. PRIOR TO INSTALLING THE FLEXAMAT, SEED THE SLOPE WITH SITE SPECIFIC SEED.
3. INSTALL FLEXAMAT ROLLS. THE TOP OF THE MAT SHALL EXTEND 2' PAST THE CREST OF SLOPE. TOP EDGE OF MAT SHALL BE ANCHORED 18" VERTICALLY IN ANCHOR TRENCH. AT THE TOE OF THE SLOPE, TRENCH THE MAT 18".
4. ABUT EACH SECTION OF MAT TIGHTLY TO THE PREVIOUS SECTION. INSTALL A 4' SECTION OF CURLEX II ECB UNDER THE ABUTTED FLEXAMAT PANELS, BRIDGING THE SEAM EQUALLY SO THAT 24" OF THE ECB IS UNDER EITHER MAT.

Distributed by:


 www.quicksupplydm.com
 (515)289-1271

FLEXAMAT®
SLOPE ARMORING DETAIL

